



Laundry Machine Cheat Sheet

Note: Too much soap does not wash the clothes better; it will leave residue on the clothes. Less soap will rinse out more efficiently.
Please give Peggy Trent a call with any questions or issues 817-991-7115

Top Load Washer

10 lb - \$2 ½ cup of soap

1. Add soap **before** loading machine.
2. Make sure the lid is closed then press start. Note: machine will stop if lid is lifted; but will restart once lid is closed.

Front Load Washer

Add soap to dispenser labeled "1" **before starting** the machine.

20 lb - \$3 ½ cup of soap 30 lb - \$4 ¾ cup soap
40 lb - \$5 1 cup soap 60 lb - \$6 1 ¼ cup soap

1. Make sure that all clothes are in behind the second rim. If not, you will get a "Door Shut" alarm.
2. To clear, you will need to open the door. Check to see if the clothes have cleared the second rim – and push door closed. Then pull firmly on the handle.
3. Wait a few seconds for the computer to reset; change the settings to another cycle. Then, go back and press 'Start'.
4. If machine is stuck on 15 minutes for a long time - it is probably a drain issue. This can only be solved by removing the clothes and moving them to another machine.

Dryers

SMALL (30 lb) - Multiples of \$.25, recommend at least \$.75 monitor machine end time. If more drying is required add quarters as necessary prior to the 3 minute cool down cycle.

LARGE (50 lb) - \$.75 minimum to start, recommend at least \$1. You may add quarters for more drying time until the end of the cycle. If cycle ends - it takes another \$.75 to restart this dryer and it will run for 18 minutes.